

```

import { useEffect, useRef, useState } from
'react';
import * as Haptics from 'expo-haptics';
import { findNodesWithinThreshold,
createAlertDeduper } from
'../services/ProximityEngine';
import { PROXIMITY_CHECK_INTERVAL_MS } from
'../utils/constants';

// location: { latitude, longitude } | null
// cachedNodes: array of camera nodes
currently loaded for the viewport
export function
useProximityAlerts(location, cachedNodes) {
  const [nodesInRange, setNodesInRange] =
useState([]);
  const deduperRef =
useRef(createAlertDeduper());
  const lastCheckRef = useRef(0);

  useEffect(() => {
    if (!location) return;

    const now = Date.now();
    if (now - lastCheckRef.current <
PROXIMITY_CHECK_INTERVAL_MS) return;
    lastCheckRef.current = now;

    const inRange =
findNodesWithinThreshold(location,

```

```
cachedNodes);
    setNodesInRange(inRange);

    const newlyTriggered =
deduperRef.current.getNewlyTriggered(inRange);
    if (newlyTriggered.length > 0) {

Haptics.notificationAsync(Haptics.NotificationFeedbackType.Warning).catch(() => {
    // Haptics can fail on devices
without support – alert still shows
    // in-app via nodesInRange, so this
is non-fatal.
    });
    }
    }, [location, cachedNodes]);

    return { nodesInRange };
}
```